



**LG Accolade**

**Carrier:** Verizon Wireless

---

**Software tested:** VX560V03

**How to find the software version:** On the Home screen press **Menu → Settings & Tools → Phone Info → SW/HW version**

**Note:** **BMW makes no guarantees or warranties as to the performance of each phone while connected to your BMW via Bluetooth® Wireless Technology. Furthermore, software releases by BMW, the phone supplier or the wireless carrier dated after testing might alter compatibility results.**

---

**Vehicles compatible:**

1 Series  
3 Series  
5 Series  
6 Series  
7 Series  
7 Series  
X3  
X5  
X6  
Z4

**Produced after**

March 2007  
March 2007  
March 2007  
March 2007  
March 2007 to September 2008  
November 2008  
March 2007  
April 2007  
April 2007  
March 2009

---

**Pairing Instructions:**

1. Set vehicle in pairing mode. For details please see the vehicle user's manual.
2.
  - To turn Bluetooth on at handset: On the Home screen press Menu → Settings & Tools → Bluetooth Menu → Turn On
  - To search for Bluetooth devices: On the Home screen press Menu → Settings & Tools → Bluetooth Menu → Add New Device
  - Your phone will display a list of any Bluetooth device(s) that it discovers in range and available to be paired. Select the name of the Bluetooth enabled device (e.g. BMWxxxxx) with which you are pairing and press Select. Please note that the Bluetooth enabled device name may first appear as "Handsfree".
3. Type in a passkey on the handset first (on some BMW models, the passkey that is required for this step is fixed. See the car manual for the passkey. On all other cars the passkey can



- be selected by the user).
4. The Confirm Passkey dialog appears on the display of the car:



Repeat the passkey that was used on the handset to authenticate the handset and press Confirm passkey.

---

#### Limitations:

1. **Call Waiting is not completely supported**