



**Sanyo SCP-2700**

**Carrier: Sprint**

**Software tested:** 0.900SP

**How to find the software version:** On the Home screen press **Menu → Settings/Tools → Settings → Phone Info → Version**

**Note:** **BMW makes no guarantees or warranties as to the performance of each phone while connected to your BMW via Bluetooth® Wireless Technology. Furthermore, software releases by BMW, the phone supplier or the wireless carrier dated after testing might alter compatibility results.**

**Vehicles compatible:**

1 Series  
3 Series  
5 Series  
6 Series  
7 Series  
7 Series  
X3  
X5  
X6  
Z4

**Produced after**


September 2007  
September 2007  
September 2007  
September 2007  
September 2007 to September 2008  
November 2008  
September 2007  
October 2007  
April 2008  
March 2009

**Pairing Instructions:**

1. Set vehicle in pairing mode. For details please see the vehicle user's manual.
2.
  - To turn Bluetooth on at handset: On the Home screen press Menu → Settings/Tools → Settings → Bluetooth → On/Off
  - To search for Bluetooth devices: On the Home screen press Menu → Settings/Tools → Tools → Bluetooth → Handsfree Pairing
  - Your phone will display a list of any Bluetooth device(s) that it discovers in range and available to be paired. Select the name of the Bluetooth enabled device (e.g. BMWxxxx) with which you are pairing and press Select. Please note that the Bluetooth enabled device name may first appear as "Handsfree".
3. Type in a passkey on the handset first (on some BMW models, the passkey that is required for this step is fixed. See the car manual for the passkey. On all other cars the passkey can be selected by the user).



4. The Confirm Passkey dialog appears on the display of the car:



Repeat the passkey that was used on the handset to authenticate the handset and press Confirm passkey.

---

#### Limitations:

1. **Call Waiting is not completely supported**
2. **Outgoing call**  
When make outgoing call using iDrive, handset must be on home screen. If handset is in any submenu than home screen, user will not be able to make outgoing call.
3. **No automatic audio transfer during active call after reconnecting to car kit**  
After phone reconnects automatically to car kit during an active call (Active Call screen displayed at Headunit), user has to transfer audio manually to car kit by Pressing Options -> Transfer Audio -> Bluetooth device.  
Scenarios:
  - User turns off Bluetooth on Headunit during an active call and on again.
  - User turns off Bluetooth at handset during an active call and on again.
  - User enters car with active call on handset.User takes handset out of Bluetooth range and re-enters the range area with an active call